


# Basketweave Installation Guidelines

Please refer to our standard installation guidelines for subfloor preparation.

Good subfloor preparation is essential for a trouble-free installation. The final appearance will very much depend on the quality of the subfloor over which it is installed.

Basketweave flooring materials should be removed from packaging and rested flat, at least 24 hours prior to installation. Allow to condition in the room where the installation is to take place. Room and product temperature should be kept between 18-27°C (64-81°F).

Please note that the **grain direction**  (shown below) in these products heavily influences the final appearance of the floor.

Karndean recommend dry laying a few tiles to ensure the correct layout before permanently adhering.

## Basketweave

1. Locate the centre of the room and draw a line A-B down the entire length of the room. At the centre point draw a perpendicular line C-D across the full width of the room.
2. Position the first tile in the centre. (Fig. 1)
3. Then position four planks around the square tile as shown (Fig. 2)
4. Place the next four tiles such that the grain is at right angles to the centre tile. (Fig 3) Continue the design making sure the square tiles are tessellated to give a "chess board" look as shown.
5. Dry lay the perimeter tiles before adhering
6. It is recommended that the same coloured plank is selected to form the border around the perimeter to enhance the overall appearance.

